


Assembly Instructions

8706744 BOHO CONSOLE TABLE


Product Issues? Please Call Us Before Contacting Your Retailer At 1-800-549-3300

Email customerservice@mshome.co, or visit www.mshome.co


We can help with Assembly Issues, Part Requests, Damages, & All Other Product
Related Questions





MSH-USA




10 min




Two People Required



Do not use power tools



Phillips Head (Not provided)



Replacement parts:

A - Table Top


B - Front Leg Frame

C - Back Leg x 2



D - Connecting Bar




Hardware Pack

AA x 12	BB x 02	CC x 01	DD x 04	EE x 02	FF x 04
Ø6.3x30 (mm)	Ø6.3x45 (mm)		Ø4x50mm		Ø4x20 (mm)




ANTI-TIP SET

1**AA x 4****CC x 1****2**

3**AA x 4****CC x 1****4****DD x 4**

5







6



AA x 4



CC x 1



7**BB x 2****CC x 1****8****EE x 2****FF x 4**

9

Adjustable floor leveler