Liberty Furniture
INDUSTRIES, INC
www.mylibertyfurniture.com

Assembly Instructions

ITEM NO	Description
6000HN-12P	Recliner P2 & ZW
6000OM-12P	Recliner P2 & ZW

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
Do Not plug the power cord into a power outlet until your recliner is fully assembled and in placed.

Make sure to read the instructions below before assembling your Recliner.



Step 1
Connect the headrest leadwire.



The headrest leadwire is yellow.

Step 2
Set up the back cushion(B) on the seat , and zip up the seat cushion and back cushion.





Assembly Instructions

Step 3
Ensure both clips on back(A) are aligned, then press top of back frame downward until a clicking sound is heard.



Step 4
Press the back part(C) down to the bottom of the back frame.



Step 5
Attach the power cord to the outlet found at the bottom rear of the Recliner.
Plug the transformer into a nearby outlet, still making sure it is clear of the metal base.



Notes:
1) To help prevent shock and or damage to your product only plug the power cord into a grounded outlet.
2) Read the operating instructions carefully before operating the power Recliner.

Liberty Furniture INDUSTRIES, INC
www.mylibertyfurniture.com

Operating Instructions for Triple Power Sku's

Caution: Read the important instructions below before operating your power mechanized equipment
Do not allow children to play on or operate this power mechanized equipment



Care should always be taken to assure there is nothing in the path of the mechanism before and during operation.

Open Recline and Headrest: The function of this button is unique in that it opens both the reclining mechanism and the headrest simultaneously. Once you are at your desired position simply remove your finger from the button. If you continue to press the button, the reclining and headrest mechanism will open to a preset position for your comfort.

Adjust Headrest: By pressing this button you can adjust the headrest forward only. Once you are at your desired position simply remove your finger from the button.

Close Headrest: By pressing this button the headrest will return to the closed/ home position. Or once you get to your desired posifion simply remove your finger from the button. By closing the headrest while in the full recline position will allow you to enjoy the maximum comfort of your product.

Home / Close Recliner and Footrest: By pressing this button you can close all functions simultaneously to its fully closed position. Or once your at your desired position simply remove your finger from the button.

NOTE:

Use a soft dry cloth to clean.
For proper support, the center leveler must be adjusted down to touch the floor.

⚠ WARNINGS & CAUTIONS

- To avoid injury, use care when assembling.
- Use on level surface.
- Adult supervision when used by children.
- Maximum load 158 kg / 350 lb.
- Exceeding this weight may damage product and cause potential injury.
- For indoor use only.
- To avoid any risk of suffocation to children or pets, dispose of all plastic bags immediately.
- To ensure proper performance, occasionally check for loose screws and tighten as needed.

Product Protected By Following Patents:
Patented Articulating Power Headrest
US Patent: 10,736,423

01185B



Liberty Furniture

INDUSTRIES, INC

www.mylibertyfurniture.com

Customer Service

If you have any questions regarding the use of this unit, or find that your unit need service, please contact your retailer.